


# Hose Barb Fittings



See Page 147 for plastic hose barb fittings

**•Temperature and Working Pressure Ranges**

From -40°F to + 160°F at 150 PSI maximum.

**See Page 160 for hose clamps**

**•Material**


CA360 Brass for Barstock fittings.

CA377 Brass for Forged fittings.

**Note:** These fittings are intended for use with hose clamp, similar type clamp or a crimped ferrule


**•Assembly Instructions**

- 1 - Cut hose cleanly and squarely to length.
- 2 - Slide clamp on hose
- 3 - Lubricate hose. Push hose on fitting until hose bottoms against stop ring or hex.
- 4 - Position hose clamp as shown below and secure with a screwdriver or wrench. Maintain "A" dimension noted below for proper clamp positioning.



Hose Size	A
3/16"	1/4"
1/4"	1/4"
5/16"	1/4"
3/8"	1/8"
1/2"	1/8"
5/8"	1/8"
3/4"	1/8"

**Actual Profile of Hose Barbs**



# Brass Fittings

**Hose Barb**

**Hose Barb**

**RIGID MALE ADAPTER**

PGH  
101  
102  
201A



125HBL  
105B-1  
KF-PS  
MPB

**HOSE I.D. X MALE PIPE**

Part #	Size
180-02-1/16B	1/8x1/16
180-02-02B	1/8x1/8
180-02-04B	1/8x1/4
180-03-02B	3/16x1/8
180-03-04B	3/16x1/4
180-04-1/16B	1/4x1/16
180-04-02B	1/4x1/8
180-04-04B	1/4x1/4
180-04-06B	1/4x3/8
180-04-08B	1/4x1/2
180-05-02B	5/16x1/8
180-05-04B	5/16x1/4
180-05-06B	5/16x3/8
180-05-08B	5/16x1/2
180-06-02B	3/8x1/8
180-06-04B	3/8x1/4
180-06-06B	3/8x3/8
180-06-08B	3/8x1/2
180-06-12B	3/8x3/4
180-08-02B	1/2x1/8
180-08-04B	1/2x1/4
180-08-06B	1/2x3/8
180-08-08B	1/2x1/2
180-08-12B	1/2x3/4
180-08-16B	1/2x1
180-10-04B	5/8x1/4
180-10-06B	5/8x3/8
180-10-08B	5/8x1/2
180-10-12B	5/8x3/4
180-10-16B	5/8x1
180-12-06B	3/4x3/8
180-12-08B	3/4x1/2
180-12-12B	3/4x3/4
180-12-16B	3/4x1
180-16-06B	1x3/8
180-16-08B	1x1/2
180-16-12B	1x3/4
180-16-16B	1x1
180-20-16B	1-1/4x1

**SWIVEL MALE ADAPTER**

Rotation 360°



SMS  
103

**HOSE I.D. X NPTF**

Part #	Size
180MS-04-04B	1/4x1/4
180MS-06-04B	3/8x1/4
180MS-06-06B	3/8x3/8
180MS-08-06B	1/2x3/8
180MS-08-08B	1/2x1/2
180MS-12-12B	3/4x3/4

**MENDER / SPLICER**



MSB  
122HBL  
HM  
129  
178  
73  
108

**HOSE I.D. X HOSE I.D.**


Part #	Size
115SB-02-02B	1/8
115SB-03-03B	3/16
115SB-04-04B	1/4
115SB-05-05B	5/16
115SB-06-06B	3/8
115SB-08-08B	1/2
115SB-10-10B	5/8
115SB-12-12B	3/4

See Bronze insert fittings on page 191 for longer sizes.

See Hose Clamps on page 160

**Male NPT x Female NPT  
360° turning swivel fitting**

360° Turning



Part #	Size
320-061	1/4

*Send DF Burnham & Company  
all your high volume quotes!*

**Brass**



# Brass Fittings

**Hose Barb**

**Hose Barb**

**RIGID FEMALE ADAPTER**

209A  
128  
29A  
29F  
126HB  
126




FPB  
105B-2  
KF-RS  
104

**HOSE I.D. X FEMALE PIPE**

Part #	Size
103SB-02-02B	1/8x1/8
103SB-02-04B	1/8x1/4
103SB-03-02B	3/16x1/8
103SB-03-04B	3/16x1/4
103SB-04-02B	1/4x1/8
103SB-04-04B	1/4x1/4
103SB-04-06B	1/4x3/8
103SB-05-02B	5/16x1/8
103SB-05-04B	5/16x1/4
103SB-05-06B	5/16x3/8
103SB-05-08B	5/16x1/2
103SB-06-02B	3/8x1/8
103SB-06-04B	3/8x1/4
103SB-06-06B	3/8x3/8
103SB-06-08B	3/8x1/2
103SB-08-04B	1/2x1/4
103SB-08-06B	1/2x3/8
103SB-08-08B	1/2x1/2
103SB-12-12B	3/4x3/4
103SB-16-12B	1x3/4

**SWIVEL FEMALE ADAPTER  
With Gasket**

130  
126  
29FSG  
KF-RN




5/Bag  
NPF  
  
NPSM-  
GASKET SEAT

**HOSE I.D. X NPSM**

Part #	Size
32-120	1/4x1/8
32-121	1/4x1/4
32-129	1/4x3/8
32-130	5/16x1/4
32-122	3/8x1/4
32-123	3/8x3/8
32-354	3/8x1/2
32-124	1/2x3/8
32-125	1/2x1/2
32-117	1/2x3/4
32-118	5/8x3/4
32-119	3/4x3/4

**FORGED HOSE BARB  
90° ELBOW**




129  
HBE1  
KF-PS90  
HE-1  
29E  
139

**HOSE I.D. X MALE PIPE**

Part #	Size
190SB-03-02B	3/16x1/8
190SB-03-04B	3/16x1/4
190SB-04-02B	1/4x1/8
190SB-04-04B	1/4x1/4
190SB-04-06B	1/4x3/8
190SB-05-02B	5/16x1/8
190SB-05-04B	5/16x1/4
190SB-05-06B	5/16x3/8
190SB-06-02B	3/8x1/8
190SB-06-04B	3/8x1/4
190SB-06-06B	3/8x3/8
190SB-06-08B	3/8x1/2
190SB-08-04B	1/2x1/4
190SB-08-06B	1/2x3/8
190SB-08-08B	1/2x1/2
190SB-10-06B	5/8x3/8
190SB-10-08B	5/8x1/2
190SB-10-12B	5/8x3/4
190SB-12-08B	3/4x1/2
190SB-12-12B	3/4x3/4
190SB-12-16B	3/4x1
190SB-16-12B	1x3/4

See Bronze insert fittings on page 191 for larger sizes

**BARSTOCK HOSE BARB  
90° ELBOW**



129HB

**HOSE I.D. X MALE PIPE**

Part #	Size
190BS-03-02B	3/16x1/8
190BS-04-02B	1/4x1/8
190BS-04-04B	1/4x1/4
190BS-06-04B	3/8x1/4
190BS-06-06B	3/8x3/8
190BS-08-06B	1/2x3/8




# Brass Fittings

**Hose Barb**

**Hose Barb**

**HOSE BARB TEES**



32-128

Part #	Size
32-367 .....	1/8
32-365 .....	1/4
32-366 .....	5/16
32-126 .....	3/8
32-400 .....	1/2
23-128 .....	3/8x1/4 MIP Branch

See Bronze insert fittings on page 191 for larger sizes

**90° HOSE BARB ELBOW**



**HOSE I.D X HOSE I.D.**

Part #	Size
32-412 .....	1/4x1/8
32-413 .....	1/4x1/4
32-414 .....	3/8x1/8
32-415 .....	3/8x1/4
32-416 .....	3/8x3/8
32-417 .....	3/8x1/2
32-418 .....	1/2x1/4
32-419 .....	1/2x3/8
32-420 .....	1/2x1/2

**90° FEMALE HOSE BARB ELBOW**



**HOSE I.D. X FEMALE PIPE**

Part #	Size
32-401 .....	1/4x1/8
32-402 .....	1/4x1/4
32-403 .....	3/8x1/8
32-404 .....	3/8x1/4
32-405 .....	3/8x3/8
32-406 .....	3/8x1/2
32-407 .....	1/2x1/4
32-410 .....	1/2x3/8
32-411 .....	1/2x1/2

See hose clamps on page 160


**90° HOSE BARB X SWIVEL MALE PIPE**



**HOSE I.D. X MALE PIPE**

Part #	Size
190SB-04-02MSB .....	1/4x1/8
190SB-04-04MSB .....	1/4x1/4
190SB-06-02MSB .....	3/8x1/8
190SB-06-04MSB .....	3/8x1/4
190SB-06-06MSB .....	3/8x3/8
190SB-06-08MSB .....	3/8x1/2
190SB-08-04MSB .....	1/2x1/4
190SB-08-06MSB .....	1/2x3/8
190SB-08-08MSB .....	1/2x1/2

**45° ELBOW ELBOW**



140  
HE145  
139HB  
KF-PS45  
139

**HOSE I.D. X MALE PIPE**

Part #	Size
145SB-04-02B .....	1/4x1/8
145SB-04-04B .....	1/4x1/4
145SB-06-02B .....	3/8x1/8
145SB-06-04B .....	3/8x1/4
145SB-06-06B .....	3/8x3/8
145SB-08-04B .....	1/2x1/4
145SB-08-06B .....	1/2x3/8
145SB-10-06B .....	5/8x3/8



**Brass**

**BALLSEAT FITTINGS**

**BALL END SWIVEL**

NPSM  
BALL SEAT  
TYPE



128HBLSV  
29FS  
209AS  
124  
131

**HOSE I.D. X NPSM**

Part #	Size
119BS-02-02B	1/8x1/8
119BS-03-02B	3/16x1/8
119BS-03-04B	3/16x1/4
119BS-04-02B	1/4x1/8
119BS-04-04B	1/4x1/4
119BS-04-06B	1/4x3/8
119BS-05-04B	5/16x1/4
119BS-06-04B	3/8x1/4
119BS-06-06B	3/8x3/8
119BS-06-08B	3/8x1/2
119BS-08-06B	1/2x3/8
119BS-08-08B	1/2x1/2
119BS-12-12B	3/4x3/4

**BALLSEAT MALE ADAPTER**

Beveled Seat




134  
127HB  
122AS  
172

**NPSM X MALE PIPE**

Part #	Size
816BS-02-02B	1/8x1/8
816BS-04-02B	1/4x1/8
816BS-04-04B	1/4x1/4
816BS-06-04B	3/8x1/4
816BS-06-06B	3/8x3/8
816BS-08-06B	1/2x3/8
816BS-08-08B	1/2x1/2
816BS-12-12B	3/4x3/4

**HOSE BARB X FLARE ADAPTER**

**45° FLARE ADAPTER**




142  
201BF  
KF-MS

**HOSE I.D. X 45° FLARE**

Part #	Size
32-322	3/16x1/4
32-081	1/4x1/4
32-082	1/4x3/8
32-083	5/16x5/16
32-084	3/8x3/8

**FEMALE 45° FLARE ADAPTER**



29SAE  
209ASF  
146HBLFSV  
KF-NS  
128  
FSS  
146

**HOSE I.D. X 45° FLARE**

Part #	Size
32-326	3/16x3/16
32-107	3/16x1/4
32-101	1/4x1/4
32-102	1/4x5/16
32-103	1/4x3/8
32-104	5/16x5/16
32-327	5/16x3/8
32-105	3/8x3/8
32-106	3/8x1/2
32-100	1/2x1/2

**FEMALE 37° J.I.C. FLARE SWIVEL**

**HOSE I.D. X 37° FLARE**



Part #	Size
119SB-04-06B	1/4x3/8
119SB-05-06B	5/16x3/8
119SB-06-06B	3/8x3/8
119SB-12-12B	3/4x3/4
119SB-16-16B	1x1

Send DF Burnham & Company  
all your high volume quotes!

Brass



**HOSE BARB X FLARE ADAPTER**

**DUAL 45° / 37° FLARE SWIVEL**



**HOSE I.D. X DUAL SEAT**

Part #	Size
119SB-04-04B .....	1/4x1/4
119SB-05-05B .....	5/16x5/16
119SB-06-08B .....	3/8x1/2
119SB-08-08B .....	1/2x1/2
119SB-08-10B .....	1/2x5/8

**INVERTED FLARE SWIVEL**



**HOSE I.D. X INVERTED FLARE**

Part #	Size
32-369 .....	1/4x1/4
32-370 .....	5/16x5/16
32-371 .....	3/8x3/8
32-372 .....	1/2x1/2
32-373 .....	5/8x5/8

See page 81 for Beaded Hose Barbs

**BRASS WELDING CONNECTORS**

• Combine type of nut needed with proper stem size to get your required configuration

**STEM ONLY**



201RWA  
WRS  
WLS

Part #	Size
30-410 .....	3/16
30-411 .....	1/4
30-412 .....	5/16
30-413 .....	3/8

**RIGHT HAND 9/16-18 FOR OXYGEN LINE**



201RWA  
WRS  
KR-PE  
152

Part #	Size
30-420 .....	R.H. Nut Only

**LEFT HAND 9/16-18 FOR ACETYLENE LINE**



209LWA  
WLS  
154  
KF-RE

Part #	Size
30-421 .....	L.H. Nut Only

**WELDING HOSE ADAPTERS**

**RIGHT HAND 9/16-18 #122RWA**



Part #	Size
30-401 .....	1/4-18

**LEFT HAND 9/16-18 #122LWA**



Part #	Size
30-406 .....	1/4-18



# Brass Fittings

**Hose Barb**

**Hose Barb**

## STAINLESS STEEL HOSE BARB

### 304 STAINLESS STEEL HOSE NIPPLES



Part #	Hose I.D. x Male Pipe
73-951	1/4"
73-952	3/8"
73-953	1/2"
73-954	3/4"
73-955	1"
73-956	1-1/4"
73-957	1-1/2"
73-958	2"
73-959	2-1/2"
73-960	3"
73-961	4"

### 304 STAINLESS STEEL REDUCING HOSE NIPPLES

Part #	Barb x Male Pipe
73-970	1/4x1/4
73-971	3/8x1/4
73-972	1/2x3/8
73-973	1/2x1/4
73-974	3/4x1/2
73-975	1x3/4
73-976	1x1/2
73-977	1-1/4x1
73-978	1-1/4x3/4
73-979	1-1/2x1-1/4
73-980	1-1/2x1
73-981	2x1-1/2
73-982	2x1-1/4

### 316 STAINLESS STEEL HOSE NIPPLES

Part #	Barb x Male
973-951	1/4"
973-952	3/8"
973-953	1/2"
973-954	3/4"
973-955	1"
973-956	1-1/4"
973-957	1-1/2"
973-958	2"
973-959	2-1/2"
973-990	3"
973-991	4"

## BRASS MALE SWIVEL HOSE BARBS

### MALE SWIVEL



4015  
6065  
8085

### HOSE I.D. X MALE PIPE

Part #	Size
180MS-04-04B	1/4x1/4
180MS-06-06B	3/8x3/8
180MS-08-08B	1/2x1/2

See page 11 for more Male Swivel fittings

### HI VOLUME MALE SWIVEL



4065

### HOSE I.D. X MALE PIPE

Part #	Size
32-781	3/8x1/4



300 PSI MAX.  
WORKING  
PRESSURE

### HOSE I.D. X MALE BALL SWIVEL

Part #	Size
28-415	1/4x1/4
28-417	3/8x1/4

## REUSEABLE HOSE COUPLINGS



183

### 1/4" MALE THREAD I.D. X O.D.

Part #	Size
32-725	3/8x3/4(23/32)
32-726	1/4x5/8
32-727	1/4x1/2
32-728	1/4x19/32
32-741	5/16x5/8
32-742	3/8x5/8

More sizes and configurations available

*Send DF Burnham & Company  
all your high volume quotes!*

